



- a.) REFER TO BILL OF MATERIALS LIST WHEN ORDERING PARTS.
- b.) REFER TO CARE & DP. MANUAL FOR ADDITIONAL INFO.
- c.) INSTALLER SUPPLIED SUPPORT PLATE MUST BE USED.
- d.) REFER TO TWIN DISC STANDARD S364R FOR COLLAR & BEARING LUBRICATION AND MAINTENANCE PROCEDURES.
- e.) DIMENSIONS WITHOUT TOLERANCES ARE FOR REFERENCE ONLY.

[illegible]